

Manual, Assembly instruction: Brodit 855309

Center mount

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Press the thin end of the enclosed gap opener into the gap between the frame surrounding the air vent and the dashboard, to widen the gap. Press/Hook the angled edge on the lower part of the ProClip into the gap between the center console and the dashboard.

2. Hook the angled edge on the upper part of the ProClip into the gap next to the gap opener. Pull out the gap opener.

3. This ProClip can also be attached above the right air vent. **4** The ProClip is in place.