

Manual, Assembly instruction: Brodit 855312

Angled mount



Please read all of the instructions and look at the pictures before attaching the ProClip. This ProClip consists of two parts: Part 1. Attaching part (smallest part). Part 2. ProClip mounting plate.

1. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Press the thin end of the enclosed gap openers into the gap between the frame surrounding the control panel and the dashboard, to widen the gap (placed as shown in the photos). Peel off the adhesive tape cover on Part 1.

2. Press the angled edge on Part 1 into the gap between the gap openers. Rotate Part 1 to the right and press forward so the angled edge hooks behind the frame surrounding the control panel and the adhesive tape attaches to the dashboard. Pull out the gap openers.

3. Peel off the adhesive tape cover on Part 2. Place Part 2 onto Part 1 so the holes match. Press the left edge of Part 2 forward so the adhesive tape attaches. Use the enclosed screws to attach Part 2 onto Part 1.

4. The ProClip is in place.