

Manual, Assembly instruction: Brodit 855313

Center mount



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Press the lower edge of the ProClip into the gap between the center console and the dashboard.

2. Press the thin edge of one the enclosed gap opener into the gap between the frame surrounding the air vent and the dashboard, to widen the gap. Press the gap opener back a little to open the gap a little wider. In the same time, press the angled edge on upper part of the ProClip into the gap next to the gap opener. Use both enclosed gap openers if needed. Pull out the gap opener/openers.

3. The ProClip mount is in place.

4. The ProClip mount is in place.