

Manual, Assembly instruction: Brodit 855315

Angled mount



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Peel off the adhesive tape cover. Press the angled edge on the upper part of the ProClip into the gap between the dashboard and the center console.
2. Press the ProClip downward/forward so the upper angled edge hooks behind the dashboard.
3. Press forward on the bottom of the ProClip so the angled edge on the lower part hooks into the gap in the center panel.
4. The ProClip is in place.