

Manual, Assembly instruction: Brodit 855318

Angled mount



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Use the enclosed alcohol pad to clean the area where the ProClip will be installed. Peel off the adhesive tape cover on the ProClip. Press the right edge of the ProClip into the gap between the frame surrounding the air vent and the dashboard.

2. Rotate the ProClip to the left, in the same time press forward so the right edge goes all the way into the gap and hooks behind the dashboard.

3. Press forward on the left side of the ProClip so the left edge hooks over the frame surrounding the air vent. Press firmly on the ProClip so the adhesive tape attaches properly.

4. The ProClip is in place.