

Manual, Assembly instruction: Brodit 855319

Angled mount

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Press the thin end of the enclosed gap opener into the gap between the panel surrounding the control panel and the center console, to widen the gap. Peel off the adhesive tape cover on the ProClip. Hook the lower edge of the ProClip under the lower edge of the center console.

2. Pull the ProClip towards you and hook the upper angled edge into the gap next to the gap opener.

3. Press forward on the ProClip so the angled edge goes all the way into the gap and the adhesive tape attaches properly. Pull out the gap opener.

4. The ProClip is in place.