

Manual, Assembly instruction: Brodit 855326

Center mount

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Peel off the adhesive tape covers on the ProClip. Place the right part of the ProClip inside the right part of the air vent.
2. Press forward on the left side of the ProClip so it snaps into place inside the frame surrounding the air vent.
3. The ProClip mount is in place.
4. The ProClip mount is in place.