

Manual, Assembly instruction: Brodit 855327

Angled mount

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Press the angled edge on the lower part of the ProClip into the gap between center mount and the dashboard. Press the ProClip upward and forward so the angled edge hooks behind the center console.

2. Hook the angled edge on the upper part of the ProClip into the gap between the frame surrounding the air vents and the dashboard.

3. The ProClip mount is in place.

4. The ProClip mount is in place.