

Manual, Assembly instruction: Brodit 855328

Angled mount



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Press the angled edge on the lower part all the way against the gap of the ProClip, into the gap between the lower section of the control panel and the dashboard. Press the ProClip inwards and upward/forward so the angled lower edge hooks behind the control panel.
2. Hook the angled edge on the upper part of the ProClip into the gap between the control panel and the dashboard.