

Manual, Assembly instruction: Brodit 855329

Center mount

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Peel off the adhesive tape cover on the ProClip. Press the angled edge on the upper part of the ProClip into the gap between the air vent and the dashboard.

2. Press the lower part of the ProClip upward and forward. Hook the angled edge on the lower part of the ProClip into the gap between the air vent and the center console.

3. The ProClip mount is in place.

4. The ProClip mount is in place.