

Manual, Assembly instruction: Brodit 855333

Center mount

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip. This ProClip can be attached onto both the left and the right air vent in the center console.

1. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Peel off the adhesive tape cover on the ProClip. Press the upper edge of the ProClip into the upper part of the air vent.

2. Press the upper part of the ProClip upward so the adhesive tape attaches. In the same time press the ProClip forward.

3. Press the lower part of the ProClip forward and upward and hook the lower edge into the gap between the center console and the frame surrounding the air vents.

4. The ProClip is in place.