

Manual, Assembly instruction: Brodit 855337

Center mount



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Peel off the adhesive tape cover on the ProClip. Press the angled edge on the lower part of the ProClip into the gap between the air vent dial and the surrounding frame.
2. Press the upper part of the ProClip downward so it flexes. Hook the notched edge on the upper part of the ProClip under the frame surrounding the air vent.
3. This ProClip will also fit onto the right vent.
4. The ProClip is in place.