

Manual, Assembly instruction: Brodit 855340

Center mount NOT for R Link.

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Press the thin end of the enclosed gap opener into the gap between the frame surrounding the display and the dashboard, to widen the gap. Peel off the adhesive tape cover on the ProClip. Press the angled edge on the lower part of the ProClip into the gap next to the gap opener.

2. Press forward on the lower part of the ProClip so the angled edge goes all the way into the gap. Pull out the gap opener.

3. Press the gap opener into the gap between the center console and the dashboard. Hook the angled edge on the upper part of the ProClip into the gap next to the gap opener. Press downward on top of the ProClip so the angled edge goes all the way into the gap. Pull out the gap opener.

4. The ProClip is in place.