

Manual, Assembly instruction: Brodit 855341

Center mount

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Peel off the adhesive tape covers on the ProClip. Place the upper part of the ProClip into the upper part of the air vent.
2. Press the angled edge on the lower part of the ProClip into the gap between the frame surrounding the air vent and the dashboard.
3. This ProClip can be installed on the right air vent as well.
4. The ProClip is in place.