

Manual, Assembly instruction: Brodit 855346

Angled mount

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Press the thin end of one of the enclosed gap openers into the gap between the control panel and the surrounding center console frame, to widen the gap. Peel off the adhesive tape cover on the ProClip.
2. Press the left edge of the ProClip into the gap below the gap opener. Pull out the gap opener.
3. Press both gap openers into the gap between the center console frame and the center console. Press down on the ProClip, in the same time press leftward on the right part of the ProClip so the right edge goes into the gap between the gap openers. Pull out the gap openers.
4. The ProClip is in place.