

Manual, Assembly instruction: Brodit 855349

Angled mount



Please read all of the instructions and look at the pictures before attaching the ProClip. The ProClip can be attached any place within the width of the air vent.

1. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Peel off the adhesive tape cover on the ProClip. Press the thin end of the enclosed gap opener into the gap between the frame surrounding the air vent and the dashboard, to widen the gap.

2. Press the lower edge of the ProClip into the gap next to the gap opener. Pull out the gap opener.

3. Press forward on the upper part of the ProClip until you hear/feel the top edge snaps into place into the gap between the display screen and the dashboard.

4. The ProClip is in place.