

Manual, Assembly instruction: Brodit 855350

Angled mount NOT for models with CD slot.



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Press the left corner on the lower part of the ProClip into the gap between frame surrounding the air vent and the dashboard. Press the lower part of the ProClip upward so all of the angled edge goes into the gap.
2. Press the upper part of the ProClip forward and hook the upper edge into the gap between the dashboard and the display.
3. The ProClip mount is in place.
4. The ProClip mount is in place.