

Manual, Assembly instruction: Brodit 855356

Center mount NOT for Cool Edition.

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Peel off the adhesive tape covers on the ProClip. Press the angled edge on the upper part of the ProClip into the gap between the frame surrounding the air vent and the dashboard.

2. Press the thin end of the enclosed gap opener into the gap between the panel surrounding the air vent and the dashboard, to widen the gap. Press the angled edge on the lower part of the ProClip into the gap next to the gap opener. Pull out the gap opener.

3. This ProClip can also be attached on the right air vent.

4. The ProClip is in place.