

Manual, Assembly instruction: Brodit 855361

Center mount



Please read all of the instructions and look at the pictures before attaching the ProClip. It is important to place the ProClip in the exact same position as shown in the pictures.

1. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Peel off the adhesive tape cover on the ProClip. Place the notched edge on the left part of the ProClip inside the frame surrounding the air vent.

2. Press the right part of the ProClip to the left. At the same time, press the right edge of the ProClip into the air vent opening. Press until you hear/feel it snaps into place.

3. The ProClip mount is in place.

4. The ProClip mount is in place.