

Manual, Assembly instruction: Brodit 855362

Angled mount



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Peel off the adhesive tape cover on the ProClip. Place the thin angled edge of the left part of the ProClip into the gap between the air vent and the surrounding frame. The top of the mount should be placed at the bend on the right side of the vent frame.

2. Press/flex the right edge of the ProClip to the left. At the same time, press forward on the right part of the ProClip so the notched edge hooks onto the frame surrounding the air vent.

3. The ProClip mount is in place.

4. The ProClip mount is in place.