

Manual, Assembly instruction: Brodit 855365

Center mount

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Press the thin end of the enclosed gap opener into the gap between the dashboard and the panel surrounding the display, to widen the gap. Peel off the adhesive tape cover on the ProClip. Press the angled edge on the upper part of the ProClip into the gap next to the gap opener. Press the angled edge all the way into the gap. Pull out the gap opener.

2. Pull the ProClip towards you, and hook the angled lower edge around the frame surrounding the air vent frame.

3. This ProClip can be attached anywhere within the width of the air vent.

4. The ProClip is in place.