

Manual, Assembly instruction: Brodit 855367

Center mount



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Press the thin end of the enclosed gap opener into the gap between the frame surrounding the speedometer and the dashboard, to widen the gap. Peel off the adhesive tape cover on the ProClip. Press the angled edge on the left part of the ProClip into the gap next to the gap opener. Press the ProClip to the right/forward so the left angled edge hooks behind the speedometer frame. Pull out the gap opener.

2. Press the gap opener into the gap in the upper left corner of the frame around the display screen.

3. Press the ProClip to the left. Insert/Press the thin edge on the right side of the ProClip into the gap below the gap opener. Pull out the gap opener.

4. The ProClip is in place.