

Manual, Assembly instruction: Brodit 855378

Center mount



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Peel off the adhesive tape cover on the ProClip. Press the thin end of the enclosed gap opener into the gap between the display screen and the panel in front of it, to widen the gap. Press a corner of the angled edge on the upper part of the ProClip into the gap next to the gap opener. Press all of the angled edge on the upper part of the ProClip into the gap next to the gap opener. Pull out the gap opener.

2. Press the gap opener into the gap between the trim and the dashboard. Pull the lower edge of the ProClip downward and hook the angled edge into the gap next to the gap opener. Pull out the gap opener.

3. The ProClip mount is in place.

4. The ProClip mount is in place.