

Manual, Assembly instruction: Brodit 855379

Center mount

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Peel off the adhesive tape cover on the ProClip. Place the notched left edge of the ProClip onto/over the inside edge of the frame surrounding the air vent. The ProClip should attach in the upper left corner of the vent frame.

2. Hook the notched right edge of the ProClip onto/over the inside edge of the frame surrounding the air vent.

3. The ProClip mount is in place.

4. The ProClip mount is in place.