

Manual, Assembly instruction: Brodit 855383

Angled mount

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip. 1. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Peel off the adhesive tape covers on the ProClip. Place the grooved edge on the left part of the ProClip onto the frame surrounding the air vent.

2. Press the ProClip leftward and press the right edge into the air vent. Press on the right side of the ProClip so the grooved edge snaps onto the frame surrounding the air vent.

3. The ProClip mount is in place.

4. The ProClip mount is in place.