

Manual, Assembly instruction: Brodit 855386

Center mount

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Peel off the adhesive tape cover on the ProClip. Press the upper part of the ProClip all the way into the upper side of the air vent, until the upper part of the ProClip presses against the padded part of the dash. See photo.

2. Rotate/Press the ProClip downward. Press the lower angled edge of the ProClip upward into the gap between the bottom of the frame around the air vent and the panel below it. Press the ProClip forward until the thin lower edge goes into the gap. The vent frame will bow up a little but will flex back down when the ProClip goes into the seam.

3. This ProClip can be placed anywhere within the width of the air vent.

4. The ProClip is in place.