

Manual, Assembly instruction: Brodit 855388

Center mount



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Remove the adhesive tape covers on the ProClip. Hook the left edge of the ProClip over the frame surrounding the instrument panel.
2. Press the right side of the ProClip forward.
3. Hook the right edge of the ProClip around the the frame around the instrument panel.
4. The ProClip is in place.