

Manual, Assembly instruction: Brodit 855390

Center mount

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Peel off the adhesive tape covers on the ProClip. Insert the front angled edge of the ProClip into the gap between the dashboard and the padded trim. Rotate the ProClip down so the angled edge hooks under the dashboard.

2. Place your fingers behind the face plate of the ProClip and flex/pull the ProClip towards you. Hook the lower angled edge under the top edge of the air vent.

3. This ProClip can be installed anywhere within the width of the air vents.

4. The ProClip is in place.