

Manual, Assembly instruction: Brodit 855391

Angled mount, High

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Press the thin edge on the upper part of the ProClip into the gap between the frame surrounding the display and the dashboard. Press the ProClip downward so the thin upper edge hooks behind the frame surrounding the display.

2. Hook the angled edge on the lower part of the ProClip around the dashboard.

3. This ProClip can also be placed onto left side of the center console. A device installed in this position may block the display.

4. The ProClip is in place.