

Manual, Assembly instruction: Brodit 855393

Center mount

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Peel off the adhesive tape covers on the ProClip. Place the grooved edge on the right part of the ProClip on the inside of the frame surrounding the air vent.
2. Press the ProClip rightwards and press the left edge into the air vent.
3. Press forward on the left edge of the ProClip so the grooved edge snaps onto the inside of frame surrounding the air vent.
4. The ProClip is in place.