

Manual, Assembly instruction: Brodit 855400

Angled mount

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Peel off the adhesive tape covers on the ProClip. Hook the angled edge on the lower part of the ProClip under the trim.
2. Pull the ProClip upwards. Hook the angled edge on the upper part of the ProClip over the panel.
3. Press downward on top of the ProClip so the adhesive tape attaches properly.
4. The ProClip is in place.