

Manual, Assembly instruction: Brodit 855403

Center mount



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Press the thin end of the enclosed gap opener into the gap between the dashboard and the padded panel surrounding the air vents, to widen the gap. Press the angled edge on the upper part of the ProClip into the gap next to the gap opener.
2. Press downward on top of the ProClip so the angled edge goes all the way into the gap.
3. Pull the lower part of the ProClip downward and hook the lower edge under the padded panel surrounding the air vents. Pull out the gap opener.
4. The ProClip is in place.