

Manual, Assembly instruction: Brodit 855404

Center mount



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Press the thin end of the enclosed gap opener into the gap between the dashboard overhang and the panel surrounding the instrument panel, to widen the gap. Press the lower edge of the ProClip into the gap next to the gap opener. Pull out the gap opener.

2. Press the gap opener into the gap between the dashboard and the compartment. Press forward on the ProClip and hook the upper edge into the gap next to the gap opener. Pull out the gap opener.

3. The ProClip mount is in place.

4. The ProClip mount is in place.