

Manual, Assembly instruction: Brodit 855405

Angled mount



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Peel off the adhesive tape cover on the ProClip. Place the upper edge of the ProClip inside the upper part of the air vent. Press the ProClip upward, in the same time pull it slowly toward you so the angled edge goes upward into the gap between the air vent and the surrounding panel.

2. Press the lower part of the ProClip upward/forward. Hook the grooved edge on the lower part of the ProClip over the edge of the panel surrounding the air vent.

3. This ProClip can also be placed onto the left air vent. A device installed in this position may block the display.

4. The ProClip is in place.