

Manual, Assembly instruction: Brodit 855407

Center mount

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Press the thin lower edge on the ProClip into the gap between the dashboard and the frame surrounding the stereo.

2. Pull the upper part of the ProClip upward so the angled edge is free and does not touch/scratch the dashboard. Press the upper part of the ProClip forward so the angled edge is placed above the gap on top of the dashboard between the air vents.

3. Hook the angled edge on the upper part of the ProClip into the gap on top of the dashboard between the air vents. Press down on top of the ProClip so the angled edge goes all the way into the gap.

4. The ProClip is in place.