

Manual, Assembly instruction: Brodit 855408

Center mount

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Peel off the adhesive tape covers on the ProClip. Hook the angled edge on the lower part of the ProClip into the gap between the frame surrounding the air vent and the center console.

2. Press the thin end of the enclosed gap opener upward into the gap between the air vent and the surrounding frame, inside the upper part of the air vent. Press the upper part of the ProClip upward, in the same time press forward so the upper edge goes into the upper part of the air vent. Slowly pull the upper part of the ProClip toward you so the angled edge goes into the gap next to the gap opener. Pull out the gap opener.

3. This ProClip can be placed anywhere within the width of the air vent.

4. The ProClip is to be installed.