

Manual, Assembly instruction: Brodit 855409

Center mount

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Hook the grooved edge on the lower part of the ProClip over the frame surrounding the air vent.
2. Press downward/forward on the upper part of the ProClip. Hook the grooved edge under the frame surrounding the air vent.
3. The ProClip mount is in place.
4. The ProClip mount is in place.