

Manual, Assembly instruction: Brodit 855410

Center mount



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Press the thin end of the enclosed gap opener into the gap between the panel surrounding the air vent and the dashboard, to widen the gap. Peel off the adhesive tape cover on the ProClip. Press the angled edge on the lower part of the ProClip into the gap between the air vent and the surrounding panel.

2. Press the upper part of the ProClip forward and hook the angled upper edge into the gap next to the gap opener. Press down on top of the ProClip so the angled edge goes all the way into the gap. Pull out the gap opener.

3. This ProClip can be placed anywhere within the width of the air vent.

4. The ProClip is in place.