

Manual, Assembly instruction: Brodit 855412

Center mount

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Peel off the adhesive tape covers on the ProClip. Place the lower part of the ProClip into the lower part of the air vent so the groove beneath the adhesive tape hooks over the corner of the frame surrounding the air vent.
2. Press forward on the upper part of the ProClip so the grooved upper edge hooks under the frame surrounding the air vent.
3. This ProClip can be placed anywhere within the width of the air vent.
4. The ProClip is in place.