

Manual, Assembly instruction: Brodit 855416

Center mount

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Press the thin end of the enclosed gap opener into the gap between the panel surrounding the air vent and the dashboard, to widen the gap. Press the angled edge on the lower part of the ProClip into the gap next to the gap opener. Pull out the gap opener.
2. Hook the angled edge on the upper part of the ProClip over the panel surrounding the display.
3. This ProClip can also be placed onto the left air vent. A device installed in this position may block the display.
4. The ProClip is in place.