

## Manual, Assembly instruction: Brodit 855417

Center mount

1.)



2.)



3.)



4.)



**Please read all of the instructions and look at the pictures before attaching the ProClip.**

1. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Press the thin end of the enclosed gap opener into the gap between the center console and the dashboard, to widen the gap. Peel off the adhesive tape cover on the ProClip. Place the right edge of the ProClip, with adhesive tape, onto the left side of the frame surrounding the air vent.

2. Press forward on the left side of the ProClip so the left edge of the ProClip hooks into the gap above the gap opener. Pull out the gap opener.

3. The ProClip mount is in place.

4. The ProClip mount is in place.