

Manual, Assembly instruction: Brodit 855420

Center mount

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip. This ProClip consist of two parts: Part 1: Attaching part Part 2: Face plate

1. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Press the thin end of the enclosed gap opener into the gap on top of the dashboard, to widen the gap. Peel off the adhesive tape cover on Part 1.

2. Press the thin edge of Part 1 into the gap next to the gap opener. Align Part 2 with Part 1. Press the thin edge of Part 2 into the gap between the dashboard overhang and the frame surrounding the control panel.

3. Rotate Part 1 downward while pressing forward to make sure the edge stays in the gap and under the top tray. Press forward on Part 2 to make sure it stays in the gap and hooks behind the panel. Use the included screws to attach the two parts together. Pull out the gap opener.

4. The ProClip is in place. The ProClip can be installed anywhere along the center dashboard area.