

Manual, Assembly instruction: Brodit 855421

Center mount



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Peel off the adhesive tape covers on the ProClip. Place the upper part of the ProClip into the upper part of the air vent so the upper edge rests onto the edge of the air vent house.
2. Hook the angled edge on the lower part of the ProClip into the gap between the frame surrounding the air vent and the frame surrounding the control panel.
3. This ProClip can be placed anywhere within the width of the air vent.
4. The ProClip is in place.