

Manual, Assembly instruction: Brodit 855423

Angled mount



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Press the thin end of the enclosed gap opener into the gap between the panel surrounding the air vents and the dashboard, to widen the gap. Peel off the adhesive tape cover on the ProClip. Press the lower edge of the ProClip into the gap next to the gap opener.

2. Press/Flip the upper part of the ProClip upward/forward so the lower edge hooks behind the dashboard. Pull out the gap opener.

3. Press the gap opener into the gap between the panel surrounding the air vents and the dashboard. Hook the angled edge on the upper part of the ProClip into the gap next to the gap opener. Press down on top of the ProClip so the angled edge goes all the way into the gap. Pull out the gap opener.

4. The ProClip is in place.