

Manual, Assembly instruction: Brodit 855424

Angled mount

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Place the ProClip over the center console frame.
2. Adjust the position of the ProClip so the angled right edge is placed by the gap in the center console sidewall.
3. Tighten the screws on the right side on the ProClip so it is properly and firmly in place.
4. The ProClip is in place.