

Manual, Assembly instruction: Brodit 855425

Angled mount



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Press the thin end of the enclosed gap opener into the gap between the frame surrounding the air vent and the dashboard, to widen the gap.

2. Press the angled edge on the lower part of the ProClip into the gap between the trim and the padded dashboard.

3. Press the upper part of the ProClip downward/forward. Hook the angled edge on the upper part of the ProClip into the gap next to the gap opener. Pull out the gap opener.

4. The ProClip is in place.