

Manual, Assembly instruction: Brodit 855426

Angled mount

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Press the thin end of the enclosed gap opener into the gap between the air vent and the surrounding frame, to widen the gap both below and above the air vent. Pull out the gap opener. Peel off the adhesive tape cover on the ProClip.

2. Press the angled edge on the lower part of the ProClip into the gap between the air vent and the surrounding frame.

3. Press the top of the ProClip downwards and hook the angled upper edge into the gap between the air vent and the surrounding frame. Wiggle the ProClip so the angled edge goes all the way into the gap.

4. The ProClip is in place.