

## Manual, Assembly instruction: Brodit 855431

Center mount

1.)



2.)



3.)



4.)



**Please read all of the instructions and look at the pictures before attaching the ProClip.**

1. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Peel off the adhesive tape cover on the ProClip. Hook the J shaped edge on the upper part of the ProClip over the front edge of the dashboard closest to the windshield.

2. Place your fingers behind the face plate and pull/flex the ProClip towards you. Hook the lower edge of the ProClip under the dashboard overhang. The tab behind the face plate should rest on the dashboard top.

3. This ProClip can also be installed above the left air vent.

4. The ProClip is in place.