

Manual, Assembly instruction: Brodit 855443

Center mount



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Peel off the adhesive tape covers on the ProClip. Place the upper edge of the ProClip into the upper part of the air vent so the adhesive tape attaches onto the inside of the upper part of the air vent.
2. Press the lower part of the ProClip upward and forward and hook the grooved lower edge over the frame surrounding the air vent.
3. The ProClip mount is in place.
4. The ProClip mount is in place.