

Manual, Assembly instruction: Brodit 855444

Center mount



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Peel off the adhesive tape cover on the ProClip. Place the left edge of the ProClip, with adhesive tape, on the inside edge of the frame surrounding the air vent.
2. Press the ProClip leftwards.
3. Press forward on the right side of the ProClip so the grooved right edge snaps behind the inside edge of the frame surrounding the air vent.
4. The ProClip is in place.